



Replacing a Wheel on your Patagonia Wheeled Luggage

Here's how to replace a wheel on your Patagonia Wheeled Luggage.

Written By: Brittany McCrigler



INTRODUCTION

It doesn't happen often, but when a wheel on your Patagonia Wheeled Luggage blows out, it can leave you stopped in your tracks. Fortunately, installing a replacement wheel is quick and only requires a single hex screwdriver.

For replacement parts or further assistance, contact [Patagonia Customer Service](#).



TOOLS:

- [Hex 4.0 Screwdriver](#) (1)
-

Step 1 — Wheel



- Lay the bag down, with the problem wheel facing you.
- ⓘ Zipping the bag closed will keep it from flopping about as you work.

Step 2



- Using a hex 4.0 screwdriver, remove the threaded bolt in the center of of the wheel. This is the screw closest to the ground when the bag is upright.
- Remove the bolt by pulling it straight out of the hole.

Step 3



- Using one hand to lift and support the bag, take the wheel in your other hand. Pull the wheel out of its casing.
 - ⓘ Removing the wheel may take a little force, do not be afraid to give it a tug.
- To install your replacement wheel, follow these steps in reverse order with your new wheel.

This document was last generated on 2017-06-20 06:32:11 PM.